





Cistermiser

OUR WORLD IS WATER

Easyflush^{EVO}

EVO 1.5"
EVO 2"
EVO CISTERN



1. Introduction


Easyflush^{EVO} is an infrared activated non-touch siphon WC flushing valve.

Available as a flush valve with a 1.5" or 2" outlet and as a flushing cistern. Non-touch activation via wave (default) or walkaway is configurable during installation.

Supplied parts


EVO 1.5" / EVO 2"

- 1 Outlet O-ring
- 2 Outlet
- 3 Outlet washer
- 4 Stem washer with boss
- 5 Outlet nut
- 6 Cap seal
- 7 Cap washer
- 8 Cap nut
- 9 Flush valve
- 10 IR Sensor unit
- 11 Sensor gasket
- 12 Sensor nut
- 13 Clamp plate
- 14 Screw packer
- 15 IR activation label
walk & wave
- 16 Mains transformer
- 17 Clamp plate fixing screw
- 18 Mains transformer
fixing screws
- 19 Battery case
- 20 Sticky pad



EVO CISTERN

- 1 Outlet O-ring
- 2 Outlet
- 3 Outlet washer
- 4 Stem washer with boss
- 5 Outlet nut
- 6 Cap seal
- 7 Cap washer
- 8 Cap nut
- 9 Flush valve
- 10 Cistern
- 11 Cistern lid
- 12 Flush pipe
- 13 Inlet Valve
- 14 IR Sensor unit
- 15 Sensor gasket
- 16 Sensor nut
- 17 Clamp plate
- 18 Screw packer
- 19 IR activation label walk & wave
- 20 Mains transformer
- 21 Clamp plate fixing screw
- 22 Mains transformer fixing screws
- 23 Battery case
- 24 Sticky pad




Optional extras

- Infrared Configuration Unit (ICU)
- Multi Product Power Supply Unit (PSUC)
- Side Front Adaptor (SFA)
- Extension cable (IFS/10)


2. Valve Operation

EasyFlush^{EVO} is a siphonic flushing valve. When a flush is activated the spill over level is lowered below the water line initiating a siphon and flushing the cistern.

Idle position



Flush position




The flush is activated by the IR Sensor unit. This can be configured to flush on a wave (default) or flush when the user walks away:

Wave (default):

To Flush


1 sec Wave = **Half Flush** 2 sec Wave = **Full Flush**



Walk Away:

Auto Flush

Presence <45 sec = **Half Flush**



Memory Flush:

If a flush is activated while the cistern is refilling, the sensor will remember the flush request and only activate when the cistern is full (to set refill time see page 12).

This is indicated by three rising green LEDs.





3. Valve Installation

Before commencing installation, isolate mains power supply and water supply.

Fit Cistern (Cistern supplied with EVO CISTERN only). Ensure cistern is mounted level.

Install Outlet fitting into Cistern.

Fit EVO Flush Valve to Outlet in cistern. Secure by rotating clockwise.



WARNING:


Cistern must be level!




4. Easyflush^{EVO} Valve Set up

Ensure the fill valve is adjusted so the water shuts off at the indicated water level on the flush valve. This is your full flush volume.

The height of the Easyflush^{EVO} flush valve water level and the filling valve float level **must** be at the same height.




Easyflush^{EVO} Flush Valve water level




Unlock

To adjust height of Easyflush^{EVO} Flushing Valve rotate upper body clockwise to release.




Adjust

Lift or lower upper body to adjust height.



Lock

Rotate anticlockwise to lock.



5. Sensor Positioning


Easyflush^{EVO} can be operated by Wave activation (default) or Walkaway activation. The installed position of the sensor will depend on your flush activation setting (see below).

Wave activation is the default setting and the WC will flush when the user's hand is placed in front of the sensor. Alternatively, with the Walkaway activation setting, the WC will automatically flush when the user leaves the cubicle.

See Config in section 12 to change the sensor activation from Wave to Walkaway.


Exposed installation

Cistern mounted sensor
(Wave activation only, default)




Concealed installation

Panel mounted sensor
(Wave activation only, default)





Concealed installation

Panel mounted sensor
(Walkaway activation only)



Drill hole to the required diameter (refer to page 8).



NOTES:


Do not position sensor near toilet roll holder or disabled bar.

Reflective surfaces and materials such as hi-vis jackets may cause the sensor to activate unexpectedly.


Walkaway version only. Minimum distance applies. If x (see diagram) is less than 12cm it is recommended that the Hand Activation is disabled. Refer to section 9.

Panel mounted sensor installation


Thin wall



Medium thickness wall



Thick wall




NOTE:


*If wall thickness is under 32mm use packer to prevent screw causing damage to sensor

Cistern mounted sensor – Wave version only

Sensor fixing



Mounting options



NOTE:

For holes between 40 and 50mm contact Cistermiser for a hole adapter. A hole diameter larger than 50mm is a non standard installation.

NOTE:

Side/front adaptor required. Not supplied with standard product but available as an extra. Contact Cistermiser for further details or order online at www.cistermiser.co.uk

6. Power Connections


Isolate mains power supply before proceeding. Mains wiring should be undertaken by a competent person.

Battery Case – Open case and fit 4 x AA (LR-6) batteries. Use fittings provided or clip onto EVO Flush Valve.


Mains Adaptor – Fasten on a panel in a dry location using screws or sticky pads provided. Connected the un-terminated cable to a 50Hz 230V AV single phase supply via a 1A fused spur (not supplied).

NOTE:


Always connect Sensor to Flush Valve before connecting power.



(1) Connect IR Sensor unit to Flush Valve (3-way connector)




(2) Connect battery pack OR mains adaptor to IR Sensor unit (2-way connector)



NOTE:

Either Battery OR Mains can be connected, not both.



NOTE:

Remove sticky label from sensor lens before use.


CAUTION:

Risk of electric shock. Isolate supply before working on wiring

Multiple power connections for Easyflush^{EVO}

If installing multiple Cistermiser products, the PSUC Multi Product Power Supply Unit is available as an accessory. Contact Cistermiser for more details.

Multi product power supply unit (Not supplied, contact Cistermiser for further details). Suitable for powering up to 10 units.




7. Testing and Commissioning

Ensure flush valve and fill valve are set to the same height level (see page 6) so the water level is at the mark on the Flush valve.

Ensure cistern is level and check for leaks.

Activate flush via sensor or manual override to verify operation.



Sensor LED Glossary

Full flush via Wave or Walkaway - 2 green LEDs single flash once per second		Scratched lens/blocked sensor - 3 red LEDs single flash once per second	
Part Flush via Wave or Walkaway - 1 green LED single flash once per second		Servo motor obstruction (Call Cisterniser for advice) - 2 red LEDs single flash once per second	
Memory flush/refilling Alternating, 3 green LEDs rising...		Sensor uncalibrated - 1 red LED single flash 4 times per second	
Low battery/power fault - 1 red LED single flash once per second			

*Amber LED = Configuration

NOTE:


For chemical water treatment. If the water system has been treated with chemical dosing, ensure the system is thoroughly flushed before fitting any Cisterniser products. Concentrated chemicals in dead legs can damage the product and result in failure. If the water is treated with Chlorine Dioxide (ClO₂), ensure concentration levels are maintained below 5ppm.

8. Maintenance

Fill valve (supplied with EVO CISTERN only): Periodically rinse the inlet filter and valve diaphragm. If the diaphragm is damaged contact Cistermiser for a replacement.

You may rinse the filter or the membrane to maintain your fill valve.

If the membrane is damaged, you need to replace it.



9. Usage advice and specification

Factory settings

Range (Wave):	~10cm
Range (Walkaway):	~55cm (~6cm for hand activation)
Refill duration after part flush:	40 seconds
Refill duration after full flush:	60 seconds
Part flush duration:	2¾ seconds
Full flush duration:	6 seconds
Power requirements:	Either 6V from 4 x alkaline AA (LR6) batteries or 6V DC regulated from mains adaptor (1A fused spur required)
Normal battery life:	27 000 cycles
Cleaning:	Clean with soap and water only
Lens care:	Infrared lens can be polished with a soft cloth

Electronic specification


Control classification:	Independent
Maximum load:	1A (6W) at 6VDC
Rated temperature range:	0-40 °C
Mains power supply:	100-250v AC 50/60Hz 1A MAX

Fill Valve (supplied with EVO CISTERN only)


Minimum working pressure:	0.1 bar
Maximum working pressure:	10 bar

10. Component dimensions

EVO 1.5 & EVO 2



EVO CISTERN



11. Advanced settings guide

Carry out only if settings need to be changed.

1 Disconnect power, wait for 5 seconds and reconnect.

2 When flashing triple **amber**.  Place hand 4-6cm from sensor until constant triple **green** LEDs, then remove hand. 

You are now in configuration mode


3 If a hand is not placed over the sensor, it will go into normal operation mode.

Wave/walkaway mode switching (this will restore default settings)

A Wait for 1 x triple **red** LEDs to enter wave/ walkaway setting



B During the triple **red** flash briefly place your hand in front of the sensor.



The sensor will flash one central **green** LED to indicate wave function, to change function put your hand in front of the sensor for 3 second.

C Sensor will flash single central **green** LED for wave mode



or double top/bottom **green** LEDs for walkaway mode



Wave sensing range adjustment (when Wave variant is selected)

A Wait for 2 x triple **red** LEDs to enter sensing range mode



B Briefly place your hand in front of the sensor until triple **green** LEDs flash slowly. Range configuration mode will then be ready.



C Move your hand to the distance from the sensor you would like to set as maximum range. Wait 8 seconds until constant triple **green** LEDs show.




Sensor distance is now set.

Walkaway sensing range adjustment (when Walkaway variant is selected)

A Wait for 2 x triple **red** LEDs to enter sensing range mode



B Briefly place your hand in front of the sensor until triple **green** LEDs flash slowly. Range configuration mode will then be ready.



C Stand at the distance from the sensor you would like to set as maximum range. Wait 8 seconds until constant triple **green** LEDs show.



Sensor distance is now set.

Full flush duration adjustment

- A** Wait for **3** x triple **red** LEDs to enter flush duration mode



- B** During the triple **red** flashing briefly place your hand in front of the sensor. The valve will start to flush and triple **green** flashing LEDs will be seen. HOLD HAND STEADY.



- C** When the valve has flushed for the desired full flush time, move your hand out of the line of sight of the sensor and triple **green** LEDs will show. The water will cease to flow and the full flush time will be set.

NOTE:

Part flush is automatically set to approximately $\frac{2}{3}$ of full flush

Refill duration adjustment

- A** Wait for **4** x triple **red** LEDs to enter refill time mode.



- B** During the triple **red** flashing, briefly place your hand in front of the sensor. The valve will flush and the cistern will refill. Triple **green** flashing LEDs will be seen.



- C** Once the cistern has refilled completely and the water has ceased to flow, move your hand back into the line of sight of the sensor and triple **green** LEDs will show. The refill time has now been set.

4

- After configuration the LEDs will flash triple **amber**, giving opportunity to re-enter configuration mode.



12. Infrared Configuration Unit (ICU) guide

NOTE: Not supplied but available from Cistermiser or any major plumbing merchant.

Button descriptions

-  Activates cleaning mode
-  Activates ICU configuration mode
-  Decreases setting
-  Increases setting
-  Checks the setting being altered
-  Saves changes and exits ICU configuration mode
-  Quits ICU configuration mode without saving changes
- 1**  Configures sensor range
- 2**  Configures full/part flush time
- 3**  Configures cistern refill time
- 4**  Toggles Wave function ON/OFF (Walkaway ONLY)
- 5**  12-hour hygiene cycle activation
- 6**  Dual flush activation
- 7**  Autorange setting of sensor range
- 8**  No function
- 9**  Switch Wave & Walkaway variants & resets to default factory settings



Entering configuration mode

Point the ICU towards the Easyflush^{EV0} sensor and press the configuration  button, LEDs will flash **amber**. Activation is most effective when the configuration button is held down as the ICU is brought close to the sensor.

It can take up to 3 seconds for the product to sense the ICU. The Easyflush^{EV0} will return to normal operation if there are no button presses for 30 seconds.

Configuring sensor range

Point the ICU at the Easyflush^{EV0} sensor and press the **1**  sensor range button (the sensor blinks **green**).

Decrease or increase the sensor range by pressing the  and  buttons respectively.

The sensor blinks red when the min or max value is reached.

Press the  button to check the sensor range setting - the sensor displays the current setting by flashing **green**; see table.

For Wave version

Number of flashes	1	2	3	4	5
Range (cm approx)	5	10	15	20	25

For Walkaway version

Number of flashes	1	2	3	4	5
Range (cm approx)	45	50	55	60	65

Save setting and exit ICU configuration mode by pressing  the button.

Exit without saving by pressing the  button.

Configuring Full/Part flush time

Point the ICU at the Easyflush^{EVO} sensor and press the **2** (⏸) flush time button (the sensor blinks **green**).

Decrease or increase the flush time by pressing the ⏪ and ⏩ buttons respectively. The sensor blinks **red** when the min or max value is reached.

Press the (OK) button to check the flush time setting - the sensor displays the current setting by flashing **green**; see table.

Number of flashes	1	2	3	4	5
Full flush time (sec)	2¼	3	4	5½	8
Part flush time (sec)	1½	2	2¾	3¾	5½

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

Configuring refill time

Point the ICU at the Easyflush^{EVO} sensor and press the **3** (⏸) refill time button (the sensor blinks **green**).

Decrease or increase the refill time by pressing the ⏪ and ⏩ buttons respectively. The sensor blinks **red** when the min or max value is reached.

Press the (OK) button to check the refill time setting - the sensor displays the current setting by flashing **green**; see table.

Number of flashes	1	2	3	4	5	6	7
Refill time (sec)	0	20	40	60	80	100	120

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

Hand wave flushing (walkaway mode only) activation and de-activation

Point the ICU at the Easyflush^{EVO} sensor and press the **4** (⏸) (the sensor blinks **green**). By default the hand wave function is on.

Pressing the ⏪ and ⏩ button switches the hand wave function on or off respectively.

Press the (OK) button to check the setting - the sensor flashes **green** once if function is off or twice if it is on.

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

12 hour hygiene flush activation and de-activation

Point the ICU at the Easyflush^{EVO} sensor and press the hygiene cycle button (the sensor blinks **green**).

Pressing the ⏪ and ⏩ buttons switches the hygiene flush function on or off respectively.

Press the (OK) button to check the setting - the sensor flashes **green** once if function is off or twice if it is on.

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

Dual flush activation and de-activation

Point the ICU at the Easyflush^{EVO} sensor and press the **6** (⏸) (the sensor blinks **green**).

Pressing the ⏪ and ⏩ buttons switches the dual flush function on or off respectively. Press the (OK) button to check the setting - the sensor flashes **green** once if function is off or twice if it is on.

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

Configuring sensor range using the autorange function

If the cubicle door is opposite the sensor, ensure that the cubicle door is closed or ajar, but not fully open.

Point the ICU at the Easyflush^{EVO} sensor and press the **7** (⏸) button.

Immediately stand clear of the sensor. Sensor blinks **green** for 5 seconds, then a steady **green** when setting complete. The sensor measures the background reflections and sets the sensor range to an appropriate setting.

Save setting and exit ICU configuration mode by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

Only possible when configured as Walkaway.

Wave/walkaway conversion / factory reset

Point the ICU at the sensor and press the **9** (R) button (the sensor blinks **green**).

Pressing the ⏪ and ⏩ button switches the function to Wave and Walkaway respectively. Press the OK button to check the setting - the sensor flashes **green** once if wave or twice if walkaway.

Save setting and exit ICU configuration by pressing the (SAVE) button.

Exit without saving by pressing the (QUIT) button.

13. Frequently asked questions

Refer to section 7 Testing and Commissioning for normal sensor function indicators after user activation

No water is entering the cistern

No obvious indicator	Ensure that the water supply is connected and the fill valve is operating correctly. Check filters for blockages.
The sensor is covered	Anti-vandal mode has been triggered. The object/debris needs to be removed from the sensor and the valve will resume normal functionality.

Flush valve not activating

The sensor light does not flash when a hand is placed in front of it.	Ensure the power supply is connected. If mains power is being used through the mains adaptor check that the mains adaptor is working by reverting to the battery pack. Remove the mains adaptor when using batteries.
Sensor is flashing single top red LED slowly, or not at all when a hand is placed in front of it.	Low or no battery power; change batteries. If operated by mains power, check wiring then contact Cisterniser.
Sensor LEDs OK	Check fill valve and flush valve are aligned with water level Ensure cistern is level Check manual activation lever is down (neutral position)
Flush volume is too low	Ensure full flush time is correct (default 3 seconds), so all water is flushed from the cistern. Refer to Easyflush ^{FV} Valve set up (section 4). Adjust flush valve and fill valve height to change full flush volume.

Continuous flow into the pan from the cistern

No obvious indicator	Water flowing through the overflow; ensure that the water entering the cistern is being shut off by adjusting the float accordingly. If the float is set too high, water will continuously flow into the cistern and out of the overflow.
-----------------------------	---

WC flushes when in use

Working as normal otherwise	Ensure that the sensor is mounted in the correct position. Refer to the Sensor positioning (section 5). Ensure the sensor range is correctly configured. Refer to the advanced setting guide (section 11).
------------------------------------	---

Other issues

Sensor flashing red middle LED 4 times per second	Sensor uncalibrated. Call Cisterniser for advice.
Sensor flashing single red top LEDs	Low or no battery power. Change batteries. If operated by mains power, check wiring then contact Cisterniser.
Sensor flashing triple red LEDs	Sensor covered or heavily scratched. Uncover or polish out scratches.
Sensor flashing double red top LEDs	Servo motor obstruction or wiring fault - Call Cisterniser for advice.

Cisterniser product warranty and extended warranty

Cisterniser products are guaranteed for 12 months from the date of manufacture. The guarantee is for faulty products and parts only: there is no labour warranty. If you believe your product is faulty, please either contact Cisterniser directly on **0118 969 1611** or at **support@cisterniser.co.uk**, with a photograph and the serial number to help diagnose the cause of the problem.

The warranty on Cisterniser products can be extended within one year of date of manufacture, at no cost, to three years from the date of installation (see details on page 20). Please make a note of the serial number and take a photograph of the installation before you leave site.

Commissioning check-list

Easyflush^{EVO}

3 YEAR
extended
warranty

The warranty on Cistermiser products can be extended within one year of date of manufacture, at no cost, to three years from the date of installation. Once the valve has been installed, complete the product commissioning checklist below to demonstrate compliance with the installation instructions. Email a photograph of this completed form to warranty@cistermiser.co.uk or post to **Cistermiser, Unit 1, Woodley Park Estate, 59-69 Reading Road, Woodley, Berks, RG5 3AN.**

Product serial number

Installation address

No	Activity	Checked	Date
1.	Ensure the cistern is installed level (check with spirit level).	<input type="checkbox"/>	<input type="checkbox"/>
2.	Ensure the Flush Valve height is set to give the correct flush volume. Ensure the Fill Valve float height is adjusted so the water line is level with the indicator on the Flush Valve.	<input type="checkbox"/>	<input type="checkbox"/>
3.	Ensure water supply is activated. For EVO CISTERN 0.1 - 10 bar.	<input type="checkbox"/>	<input type="checkbox"/>
4.	Check sensor is mounted in correct position (refer to section 5).	<input type="checkbox"/>	<input type="checkbox"/>
6.	Ensure label is removed from sensor before connecting power.	<input type="checkbox"/>	<input type="checkbox"/>
7.	Check power connections (refer to section 6).	<input type="checkbox"/>	<input type="checkbox"/>
8.	Ensure either mains or battery power or multi product power supply is connected.	<input type="checkbox"/>	<input type="checkbox"/>
9.	Check sensor range, refill time, full flush times are suitable for installation (refer to advanced settings guide section 11).	<input type="checkbox"/>	<input type="checkbox"/>
10.	Test operation.		
a	Wave: Place hand within ~10cm of sensor for 1 second = valve will part flush and the sensor will flash the single LED once per second. Place hand within 10cm of sensor for two seconds = valve will full flush and the sensor will flash the double bottom LEDs once per second.	<input type="checkbox"/>	<input type="checkbox"/>
b	Walkaway: If presence is detected, sensor flashes green once every three seconds. When sensor detects a presence for less than 45 seconds, valve will part flush. Where sensor detects a presence for over 45 seconds valve will full flush.	<input type="checkbox"/>	<input type="checkbox"/>

Davidson Holdings' brands

Salamander Pumps

Salamander is one of the UK's leading manufacturers of pumps for boosting water pressure for showers, bathrooms and whole house supply in domestic and small commercial tank-fed systems.

salamanderpumps.co.uk

Talon®

Talon is the UK market leader in the manufacture and supply of plastic pipe clips, pipe collars and fixing plugs, plus a range of cover profiles for concealing pipework.

talon.co.uk



Keraflo OUR WORLD IS WATER

Keraflo manufacture delayed action float valves, which provide an accurate and effective method of controlling the level of stored cold water in tanks both with and without raised float valve chambers. The range is used in domestic, commercial and industrial applications worldwide.

keraflo.co.uk



Combimate GUARANTEED LIMESCALE PREVENTION

Combimate is a domestic limescale prevention device that prevents limescale build-up and soft water corrosion in combination boilers and other domestic hot water appliances.

combimate.co.uk

Cistermiser Limited

Unit 1, Woodley Park Estate, 59-69 Reading Road,
Woodley, Reading, Berkshire RG5 3AN

t: +44 (0) 118 969 1611 **f:** +44 (0) 118 944 1426

e: sales@cistermiser.co.uk

cistermiser.co.uk

A Davidson Holdings company

