

Shower Curtain Rod



Fittings instruction for the following product:

D02614 - 1200mm x 1200mm Stainless Steel Shower Curtain Rod

Fixing Pack Contents

- (A) Fixing screws x 6
- (B) Wall plugs x 6
- (C) Hex head key x 1
- (D) Spare grub screw x 3

Tools Required (not supplied)

Pencil; Tape measure; Cross-head screwdriver; Spirit level; Drill; 6mm masonry drill bit (6mm ceramic drill bit optional); Fine toothed hacksaw.

KEEP DIY TOOLS OUT OF THE REACH OF CHILDREN

Note: The wall plugs supplied are for use on solid walls only. For cavity walls or plasterboard use specialist fixings that are available from all good DIY stores.

Home Safety Advice

- It is recommended that two people fit this product to ensure that it is fitted safely.
- Always take care when using power tools, particularly in the bathroom.
- Always check for hidden cables and pipework before drilling and take extreme care if there is any water in the working area.
- It is advisable to use a residual current circuit breaker (RCCB).
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.
- Always ensure that the drill hole passes through the central tiled area rather than through the grouted area. To prevent damage to the tile, mask the area around the hole with tape before drilling.
- Do not strike the product with hard or sharp objects.
- Do not use product as a grab rail.

Product Care

To retain the best quality finish, clean product regularly with a soft damp cloth. Do not use abrasive or chemical cleaners as these will damage the product.

Fitting Instruction

1. Lay out the components. Measure around the bath or shower tray to determine exact dimensions and shape. Join the rod sections together using the corner joint, tapping gently into place if required.

Note: The rod can be cut to length if required using a fine toothed hacksaw, but always cut the end of the rod which fits and is concealed within the wall bracket. Ensure the end of the rod is cut square and is deburred.

2. Measure the drop of the shower curtain to determine the position of the wall brackets, allowing for the curtain hooks and sufficient overlap in the bath or tray. Place the first wall bracket in the desired location and mark through the screw holes with a pencil. (See Fig.1)
3. Using a 6mm masonry drill, drill the hole in the marked position to a depth of 30mm. If drilling through tiles, please pre-drill using a ceramic drill bit.
4. Insert the wall plugs to the surface of the wall. If fitting to a tiled surface, the wall plug should be inserted below the surface of the tile to avoid cracking. Fix the wall bracket to the wall using the screws provided. (See Fig.2)
5. Insert the rod assembly into the fixed wall bracket and use it as a guide to position the second wall bracket. Check the assembly is horizontal (See Fig.3)
6. Secure the second wall bracket into position by repeating steps 2-4.
7. Slide the wall bracket covers and the 'C' hooks onto the rod prior to inserting the rod assembly into the wall brackets. Slide the covers over the wall brackets to conceal all fixings. Secure each cover by tightening the grub screws, one through the clearance hole of the wall bracket onto the surface of the rod, and the other onto the wall bracket. (See Fig.4)
8. Determine a suitable location for the ceiling support rod. Attach the ceiling support bracket 'A' onto the rod by clipping it in place. Measure the distance between the ceiling and the top of the ceiling support bracket 'A' and add 28mm (which is the depth of tube into the ceiling support bracket) to this dimensions (See Fig.5). Cut the ceiling support tube to the required length using a fine toothed hacksaw. Ensure the end of the tube is cut square and is deburred.
9. Assemble the ceiling bracket and bracket cover onto the ceiling support rod, check it is vertical and using a pencil to mark its screw hole positions (See Fig.6). Drill and screw the bracket to ceiling using the screw provided, either into a ceiling joist or use a cavity wall plug. Slide the cover over the bracket and secure by tightening the grub screws, one through the clearance hole on the ceiling bracket onto the surface of the rod, and the other onto the ceiling bracket (See Fig.4).
10. Secure the ceiling rod into the ceiling support bracket using a screw provided (See Fig.5). DO NOT OVERTIGHTEN. Check the curtain rod is horizontal and adjust if required.

