



Fixings for 13mm Board
 4 No. 12mm X M4 CSK machine screws
 1 No. 23mm X 4.75mm allthread
 Fixings for 20mm Board (Packed with keep)
 4 No. 20mm X M4 CSK machine screws
 1 No. 30mm X 4.75mm allthread

INWARD OPEN

1. Fold template along line and position on edge of door.
2. Mark hole centres as template.
3. Drill 4 X 7mm holes as shown.
4. Drill 2 holes 10mm dia and router slot for indicator spindle
5. Screw bolt to door through holes using machine screws provided.
(Make sure indicator spindle is located into plastic slider).
6. Fit indicator disc in correct position with peg (As shown on drawing) engaged with slot in slider
7. Snap on indicator front plate in correct position as shown.
8. Fit selected keep to pilaster ensuring adequate clearance.

OUTWARD OPEN

All as above but use dotted line to align with door edge.

Page 2 for template.

NOTE

Please check dimensions as shown on template as some printers stretch or shrink the template.

Place indicator bolt on template to check template accuracy **before** drilling.

